



Make a Boomerang



Problem

Make a boomerang that will come back

Limitations

1. None

Materials

1. 1 x Cardboard blades
2. 1 x Stapler
3. 1 x Scissors
4. Coloured pens or crayons (optional)

Method

1. Print Blades
2. Cut blades out of cardboard
3. Lay one blade on top of the other so they form an X shape, and staple or glue them together at the centre.
4. Decorate your boomerang with markers.
5. Fold up the ends of each cardboard strip about one inch from the end of each blade. Now, you are ready to fly it. Follow the tips at left.

Flying Tips

1. Find an open area outdoors away from other people.
2. With your arm raised, hold your boomerang vertically (pointing up) by one of its blades so the curved tips bend toward you.
3. Throw the boomerang with a quick snap of your wrist using just a little force. Throw it like you would a baseball.
4. Adjust the folds and practice your throw to make the boomerang fly better.



Make a Boomerang





Make a Boomerang

